

User Manual for Floater Packaging

- Floater-Packaging is evolved to protect items against damage caused by the contact with Water.
- Floater-Packaging is reusable.
- Packaging guarantees keeping packed items dry for a longer time and in the situations when waterlevel overcomes the gabarites of packaging(in drunken state)
- Waterproof zipper is used to open and close the packaging. It guarantees being waterproof and hermetic.
- When closing the packaging you have to be sure that at its end the zipper is fixed in a special nest. Only this way it will be waterproof and hermetic.

The belts are added (depending on the type of packaging):

- to fix the content of packaging (for all Floater types)
- to fix the packagings to eachother(Floater S and L)
- to fix the packagings to constructions to avoid their dislocating
- to transport items in the case of sufficient amount of water

Need for using a Floater packaging:

- by a flood after a tidal water or downpour
- when crossing waterbarriers swimming
- when using an unstable watercraft
- for transport of clothes, medicines and foodstuff into flooded areas.

When using the Floater packaging made of durable and quality materials the following must be considered:

- it must not contain sharp items which can damage the packaging
- the items in the packaging must be dry
- breakable things must not be packed (glass, mirrors)
- packaging is not for living beings (It is hermetic!)

NB!

Dragging the package along the ground is forbidden.

Storage of Floater Packaging

- Temperature must be
- The air humidity must not be over
- by a storage for longer time the protection against UV – radiation is necessary (to avoid the changes in the material structure)